

How to reattach a plug to a UniLab Powerpack

Soldering iron needs to be $\sim 400^{\circ}\text{C}$



Heat soldering iron.
Hold under tab of pin
Melt old solder
Suck it away



Remove old solder from wire.
Melt and suck



Melt new solder on
to exposed wire



Join pin and wire and
hold solder iron underneath
until fused.

Leave to cool before pulling plug over pin!